



Catalog #689780

Russell DOT Brake Hose Kit for 2006 Hummer H3

## INSTALLATION INSTRUCTIONS

Please study these instructions carefully before installing your new Russell brake hose kit. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Monday through Friday, Pacific Standard Time or e-mail us at [Edelbrock@Edelbrock.com](mailto:Edelbrock@Edelbrock.com). Please fill out and mail your warranty card.

### **IMPORTANT NOTE:**

**Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.**

### **INSTALLATION PROCEDURE**

**IMPORTANT NOTE:** Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Doing so may require removing the master cylinder from the vehicle for bench bleeding. Also, use care when handling brake fluid, as it can quickly damage finished surfaces (paint, plating, etc.).

1. Remove factory brake hoses, noting routing.
2. Install Russell front hoses similar to factory. Use factory clip to retain inboard fitting. Use supplied bolt, nylon spacer, and cushion clamp to mount hose to bottom of upper A-arm at factory bracket location (**See Figure 1**).
3. Install Russell rear outer hoses similar to factory.
4. Install Russell rear center hoses similar to factory. Use supplied e-clips to retain hose ends to factory brackets.
5. Check hose clearance throughout entire suspension and steering travel range.
6. Bleed the system and check for leaks while applying pressure.



**Edelbrock Corporation, 2700 California Street, Torrance, CA 90503**

**Toll-Free Tech Line: 1-800-416-8628**

**Office: 310-781-2222; Tech Fax: 310-972-2730**

**Tech E-Mail: Edelbrock@Edelbrock.com**