



**1997-2006 JEEP WRANGLER TJ CLUTCH HOSE KIT**  
**Catalog #694870**  
**INSTALLATION INSTRUCTIONS**

Please study these instructions carefully before installing your new clutch hose assembly. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday - Friday, Pacific Standard Time.

***IMPORTANT NOTE:***

***Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.***

**INSTALLATION**

1. Begin by locating the roll pin on both the master cylinder and the slave cylinder.
2. Remove the pins to allow the release of the hose assembly fittings.
3. Install the new Russell fittings into the master cylinder and slave cylinder using the roll pins to keep the fittings retained.
4. Install the new Russell hose assembly to the previously installed Russell fittings. Avoid installing the Russell hose in a twisted position or near any moving parts to prevent any damage to the Russell hose assembly.
5. Once the new Russell hose is installed, the system must be bled to remove any possible air from the line.
6. We recommend that you remove the master cylinder cap and slowly depress the clutch. After several depressions, the hose assembly should be bled and the slave cylinder should be operational.
7. Check the system for leaks and refill the master cylinder as necessary.

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech Line: 800-416-8628**

©2009 Edelbrock Corporation  
Brochure No. 63-694870

Page 1

Catalog #694870  
Rev. 3/09 - AJ/mc



**1997-2006 JEEP WRANGLER TJ CLUTCH HOSE KIT**  
**Catalog #694870**  
**INSTALLATION INSTRUCTIONS**

Please study these instructions carefully before installing your new clutch hose assembly. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am to 5:00 pm, Monday - Friday, Pacific Standard Time.

***IMPORTANT NOTE:***

***Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.***

**INSTALLATION**

1. Begin by locating the roll pin on both the master cylinder and the slave cylinder.
2. Remove the pins to allow the release of the hose assembly fittings.
3. Install the new Russell fittings into the master cylinder and slave cylinder using the roll pins to keep the fittings retained.
4. Install the new Russell hose assembly to the previously installed Russell fittings. Avoid installing the Russell hose in a twisted position or near any moving parts to prevent any damage to the Russell hose assembly.
5. Once the new Russell hose is installed, the system must be bled to remove any possible air from the line.
6. We recommend that you remove the master cylinder cap and slowly depress the clutch. After several depressions, the hose assembly should be bled and the slave cylinder should be operational.
7. Check the system for leaks and refill the master cylinder as necessary.

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech Line: 800-416-8628**

©2009 Edelbrock Corporation  
Brochure No. 63-694870

Page 1

Catalog #694870  
Rev. 3/09 - AJ/mc