



**Russell DOT Brake Hose Kit  
for the 2009 Ford F-150 2WD  
Part #696520  
INSTALLATION INSTRUCTIONS**

Please study these instructions carefully before installing your new Russell brake hose kit. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Monday through Friday, Pacific Standard Time.

**IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void warranty and may result in poor performance and engine or vehicle damage.**

**INSTALLATION PROCEDURE**

**IMPORTANT NOTE:** Do not allow the master cylinder to completely drain of brake fluid at any time during this process. Doing so may require removing the master cylinder from the vehicle for bench bleeding. Use care when handling brake fluid, as it can quickly damage finished surfaces (paint, plating, etc.).

1. Remove original brake hoses and any associated hardware. Cap off chassis hard lines and caliper inlets.
2. Use the supplied hardware to install the Front and Rear Left/Right Hoses as shown in Figures 1, 2 and 3.
3. Check hose clearance throughout entire steering and suspension travel range. Verify that none of the hoses were twisted or crimped during the installation process.
4. Bleed the system and check for leaks while applying pressure. Turn the steering wheel to full lock in both directions to verify the hoses will not contact any moving parts during operation.



**Edelbrock Corporation • 2700 California St. • Torrance • CA 90503**

©2010 Edelbrock Corporation  
Part #696520

**Tech Line: 800-416-8628  
Office: 310-781-2222**

Brochure #63-696520  
Rev. 4/10 - AJ/mc